

AES72 Pinouts

RJ45 Pin	1	2	3	4	5	6	7	8
T-568A Wire								
T-568B Wire								

☐ AES72-1E THE SSSNAKE	CH1-	CH1+	CH2-	CH3+	CH3-	CH2+	CH4-	CH4+
☐ AES72-3E CATCORE	CH3-	CH3+	CH2-	CH1+	CH1-	CH2+	CH4-	CH4+
☐ AES72-4E NEUTRIK, QTP, REDCO, STAGEEASY, STUDIOHUB, WARD-BECK	CH1-	CH1+	CH3-	CH2+	CH2-	CH3+	CH4-	CH4+
☐ AES72-5E ADAM HALL, PALMER	CH3-	CH3+	CH4-	CH1+	CH1-	CH4+	CH2-	CH2+
☐ AES72-6E (NOT USED)	CH4-	CH4+	CH3-	CH2+	CH2-	CH3+	CH1-	CH1+
☐ AES72-10 ELITE CORE, STAGETEC	CH1+	CH1-	CH2+	CH3-	CH3+	CH2-	CH4+	CH4-
☐ AES72-20 ELEMENT AUDIO, SESCOM*, SOUNDTOOLS, STAIRVILLE	CH2+	CH2-	CH3+	CH1-	CH1+	CH3-	CH4+	CH4-
☐ AES72-30 CAMTEC	CH3+	CH3-	CH4+	CH1-	CH1+	CH4-	CH2+	CH2-
☐ AES72-1M CODA, LINK, PRONOMIC, PROPLEX, TMB, WHIRLWIND, WISYCOM, SOUNDDEVICES	CH1+	CH1-	CH2+	CH3+	CH3-	CH2-	CH4+	CH4-
☐ AES72-3M CORDIAL, DIGIFLEX, HOSA, LYX, SOMMER	CH3+	CH3-	CH2+	CH1+	CH1-	CH2-	CH4+	CH4-
☐ AES72-6M MAUR & CO, RADIAL	CH4+	CH4-	CH3+	CH2+	CH2-	CH3-	CH1+	CH1-
☐ AES72-1B CRANBORNE AUDIO**	CH1-	CH1+	CH2-	CH3-	CH3+	CH2+	CH4-	CH4+
☐ AES72-3B THOMANN	CH3-	CH3+	CH4-	CH2-	CH2+	CH4+	CH1-	CH1+

*CH4 pins for the 3-channel extender [SES-3] are connected to ground
 **OUT 1/2 is CH 1/2 for RRTT pinout and CH 3/4 for TTRR pinout